

Mounting spacers Isaac Muon bar

This alloy part should always be mounted on the base bar:



Mounted with 2 bolts front he downside from the bar:



The plastic spacers fit perfectly in the alloy part:



Mount the right amount of spacers:



On the top of the plastic spacers the alloy part with the degrees should be mount:



Inside of this top part the bolts should be mount, take care off the right length of this bolts. The bolts will fixed in the holes from the first alloy part:



Then mount the upper part from the alloy part:



At last the carrier from the extensions should be mount on the alloy part.

